

RadioCam



RadioCam T2  
**Law Enforcement  
Camera**  
User Manual

[www.telosystems.com](http://www.telosystems.com)



**TeloSystems**  
Bridging Communication Gap

# Contents

<b>Introduction</b>	-----	03
<b>Charging The Device</b>	-----	05
<b>How To Wear The Camera</b>	-----	06
• For Standard Accessory	-----	06
• For Option Accessory	-----	08
<b>How To Operate The Camera</b>	-----	09
• Switch On & Off	-----	09
• Slide To Record	-----	09
• PTT Button	-----	10
• Infrared Illuminator	-----	11
• Snapshot Button	-----	11
• Low Battery Alarm	-----	11
• Low Storage Alarm	-----	11



# RadioCam T2

## Quick User Manual

### Introduction

**RadioCam T2 combines body worn camera and excellent radio remote speaker microphone feature all in one.**

Compact size and light weight, RadioCam T2 is meeting the trend for reducing the number of devices that first responders wearing in the field.

Please fully charge the battery for first time usage

# Operation Manual

## Overall Description



### Note:

**Charge indicator:** It's red color during charging, and it will change to green color after fully charged.

**Function indicator:** 1. During video recording, the indicator is flashing and red color.

2. When the battery is low, the indicator is green and red alternate flashing.

### Reset:

When the camera can't be turned off, you can use a needle to poke the reset hole which is near the USB interface.

# Charging The Device

## Two Methods to Charge T2

1

**Direct Connection to the  
charger with USB port**

2

**Charging by Docking Station,  
docking station will download  
camera data to the PC together**

**Note:**

When charging the camera, it is better to turn off the camera, charging can be fast and avoid heating.

# How To Wear The Camera

## For Standard Accessory



Plug the metal belt clip into the slot, and hear a “click” sound, please see below picture. And if you want to remove the belt clip, just pull it out.

**Metal Sheet**

**Gently pinch the metal sheet as the arrow points and plug it in the slot**

**Belt clip can rotate 360 Degrees**



Step

1

2

3

# How To Wear The Camera

## For Option Accessory



Klick Fast

- Plug the connector to the camera slot until hear a “click” sound, as below pictures
- Wear the camera from the down-side to the klick fast accessory, and rotate 180 degrees, installation completed, as below pictures.

Gently pinch the metal sheet as the arrow points and plug it in the slot



Step

1

2

3



**Chest  
Harness**



**T2 RadioCam with  
Klick Fast**



**Inverted T2 RadioCam**



**Plug the Klick Fast in  
the Slot**



**Rotate T2 RadioCam  
180 Degrees**





# How To Operate The Camera

## Switch On & Off

### Switch On:

Long press the Power Button until hear "Camera on".

### Switch Off:

Long press the Power Button until hear "Camera off".

## Slide To Record

After turning on the camera, slide the recording button to "ON", video recording will be started; if slide to "OFF", video recording will be stopped.

### Note:

If the camera is doing video recording for hours, the camera will have some hot, this is normal heat dissipation.



## PTT Button

The camera can connect to radio via cable, working as radio remote speaker microphone. Press the PTT button, it can push to talk, T2 is more than a body worn camera, it can replace the radio speaker microphone together.



**Note:**

T2 can work with Motorola, Hytera, Sepura, Airbus, Kenwood, radio.

**Note:**

For PTT function, the camera shall have power, if the battery is low, PTT function can't work.

When the camera has power, if client is doing PTT function, we suggest to turn off the camera, this can help to save camera battery and PTT is still working without turning on the camera, when emergency happened, client can slide camera button to record evidence. Camera PTT volume is controlled by radio volume.

## **Infrared Illuminator**

When the camera goes to the dark area or low light area, the camera will switch to the night vision automatically.

## **Snapshot Button**

When pressing this button, it will take photo and have audio indication "Snapshot".

## **Low Battery Alarm**

When the recording time less than 30 minutes, there will be alarm to remind the user, at the same time you can see the indicators flashing in green and red color.

## **Low Storage Alarm**

When the camera memory is less than 1GB, camera will have audio alarm to remind the user.